

1. Job Set-up Information

A. Fixtures, Tools, Test and Support Equipment

REFERENCE	QTY	DESIGNATION
460007242	1	ADAPTOR, TORQUE REACTION

2. Job Set-up

SUBTASK 32-11-29-941-050-A

A. Safety Precautions

Make sure that the ground safety locks are installed on the landing gear (REF Fig [32-00-00-991-00-200-A - Main and Nose Landing-Gears Safety-Devices](#)).

3. Procedure

(Ref. Fig [32-11-29-991-00100-00-B - Torque Link Damper - Location and Detail](#))

A. Removal of the Torque Link Damper

(1) Remove and discard the cable tie (8).

(2) Remove the cover (7).

WARNING: USE PROTECTIVE GOGGLES EACH TIME YOU CUT A COTTER PIN. DISCARD LOOSE OR USED COTTER PINS IMMEDIATELY. A LOOSE OR USED COTTER PIN CAN CUT YOU OR MAKE YOU BLIND.

(3) Cut, remove and discard the cotter pin (15).

(4) Remove the nut (14), washers (17) and the bolt (16).

(5) Hold the torque link pin (6) with the ADAPTOR, TORQUE REACTION ([460007242](#)) and remove the nut (13) and the spacer (12).

(6) Hold the bottom torque-link assembly and remove the items that follow:

- The torque link pin (6)
- The sleeve (11)
- The spacer (10)

(7) Carefully lower the bottom torque-link assembly.

(8) Remove the bolts (1) and the washers (2).

(9) Carefully remove the torque link damper (5).

(10) Remove the spacer (4), the spacer assembly (3) and the sleeve (9) from the top torque-link assembly.